

Operating Instruction (TPM-10)

Features

- LCD display
- Insert design
- Simple appearance
- Two button batteries for longer use time
- Especially applied in refrigerator, chiller, deepfreeze etc.

Technical parameter

- temperature range: $-50^{\circ}\text{C} \sim +70^{\circ}\text{C}$
- Using environment: Temperature: $-10^{\circ}\text{C} \sim +50^{\circ}\text{C}$
Humidity: $5\% \sim 80\%$
- Accuracy: $\pm 1^{\circ}\text{C}$
- Distinguish: 0.1°C
- Power: two button battery (AG13, 1.5v)

Instruction

- Open the battery cover to put in two AG13 batteries correctly, be assure not turn over.
- Display once put in the batteries. Pls take out the batteries when not use for long time (Notes: First use pls take out the dielectric)
- LCD display $H^{\circ}\text{C}$ when temperature is higher than 70°C ;
LCD display $L^{\circ}\text{C}$ when temperature is lower than -50°C .
- Insert size: $46 \times 26.6\text{mm}$